




# TailLight Tracker User Guide



# What's Inside

## EON TailLight Tracker



## Getting Started

### Activating Your Tracker

If you purchased your device pre-activated, you should have received an email containing your default login information before you received the device. If you did not purchase a pre-activated tracker, please visit [activate.brickhousesecurity.com](https://activate.brickhousesecurity.com) to complete your device activation.

If you can't find your login email, try these three steps:

1. Check your spam or junk folder
2. Search for “**BrickHouse Security**” in your inbox for the email subject “**Important: Your Password for GPS Login**”
3. If you still can't find it, contact: [support@brickhousesecurity.com](mailto:support@brickhousesecurity.com). Or text or call +1 (800) 654-7966 and live reps will reply back between 9am and 9pm ET.

### Verify Your Installation Tools

The TailLight Tracker does not require any wiring modifications and installs directly into the standard 4" or 6" round taillight grommet using the existing 3-pin connector on your trailer; however, you may need a screwdriver to remove the original OEM taillight during installation.

If you're unsure about installing it yourself, contact our support team to schedule an on-site installation with a certified technician.

### Before Installing the TailLight Tracker

To ensure proper power and functionality, you must verify the trailer's lighting circuit:

- 1. Turn on the running lights.**  
Confirm the existing OEM taillight illuminates normally.
- 2. Press the brake pedal or apply trailer brake power.**  
Make sure the brake light brightens correctly.
- 3. Inspect the 3-pin socket.**  
Look for corrosion, loose pins, or damaged wiring.

Only proceed when the OEM light operates correctly. The tracker relies on this circuit for power and charging.

## Removing the Existing Light

Twist and pull the existing 4" (or 6") round light out of the grommet, then disconnect it from the standard 3-pin plug.

## Installing the TailLight Tracker

1. Align the TailLight Tracker's 3-pin connector with the trailer's socket.
2. Firmly plug the device into the socket until fully seated.
3. Press the light into the rubber grommet until secure.

The tracker will receive power whenever the trailer lights are active. When the lights are off, it will switch to Smart Power Management and report based on vibration or brake activity.

## Test Drive

After installing the tracker, take your vehicle for a 15-20 minute test drive so the EON TailLight Tracker can establish a GPS connection.

## Login to Locate Platform

Using a web browser, visit [locate.brickhousesecurity.com](https://locate.brickhousesecurity.com). For all customers on a mobile device: Download and open **BrickHouse Locate GPS** app.

Sign in using your login information. **Please note:** Both the username and password are case sensitive.


## View Tracking

Once you log in you will be able to see tracking reports from your test drive.

# Mounting Guide

## Tools Required


**Optional:** A screwdriver may be needed if your existing taillight assembly uses screws to secure the grommet.



## How to Install

Installing the TailLight Tracker is quick and simple. Just remove your existing 4" or 6" round taillight, using a screwdriver only if your grommet is secured with screws then unplug the standard 3-pin connector.


Plug the same 3-pin connector into the TailLight Tracker and press the device into the existing grommet until it sits firmly in place. Once mounted, the tracker will power on whenever the trailer lights are active and begin reporting based on movement or available power.



## Device Not Powering On When Lights and Brakes Are Activated

If the TailLight Tracker does not turn on when your trailer lights or brakes are engaged, please check the internal power switch:

1. Remove the device by pulling it out of the grommet.
2. Using a screwdriver, remove the two screws securing the SIM compartment cover on the back of the device.
3. Open the compartment to access the internal switch.
4. Ensure the switch is in the ON position.
5. Reassemble the cover, reinstall the device, and test again.



# BrickHouse Locate GPS Platform

In the following pages, you will learn how to set up and customize the web interface of our Locate GPS tracking platform, as well as the mobile app, which is available in the iOS App Store and the Google Play Store. After that, you'll learn how to use some of the major platform features, like Tracks, Geofences, Notifications, and Reports.

## Customizing and Tracking Your Device via a Web Browser

To start tracking your TailLight Tracker, open a browser window and go to [www.BrickHouseSecurity.com](http://www.BrickHouseSecurity.com).

Hover your cursor over the Login tab on the top right of the website and click on GPS.



Using the temporary credentials provided by email, enter your email address and click the **Next** button. Enter your password and click **Log In**. You will be prompted to change your password. After you do that, the Monitoring page will appear, and your device's last reported location will be at the center of the map. You can also log in directly to the platform by visiting [locate.brickhousegps.com](http://locate.brickhousegps.com).


If you have already registered in the system but forgot your password, enter your email address and click **Next**. On the next page, click on the **Forgot password** link. If the entered information matches the existing data in the database, instructions for setting your password will be sent to you via email.

If you pressed 'Forgot your password?' by accident, delete the received email with a password reset link and use your previous login and password. If you follow the link, you must enter a new password. You can reset the password no more than once a minute.

## User Menu

At the right corner of the top panel, the username used to log in is displayed.

Clicking on the username opens a menu with the items listed below.



User Settings	Open user settings for viewing and/or editing.
Session Management	Open the Session management window.  Shows the list of applications with access to your account and devices that can receive mobile notifications from BrickHouse. The lists are created automatically after logging in to the application.
Locator	Opens the <u>Locator</u> dialogue box.  Allows you to share the unit location in real time.
Help	Request help from our Tech Support team.
Logout	Click here to log out of the system.


## User Settings

To choose user parameters, click on the username in the right corner of the top panel and press the 'User settings' button in the dropdown menu. Next, follow the steps:

- Indicate your time zone.
- Select the type of daylight savings time used in your region.

Please select the settings properly, as they will be used when generating reports, messages, and elsewhere throughout the system.


Indicate a city in the dialogue box to scale the map for tracking entries.



# Editing Your Unit

Make sure the device is displayed on the monitoring tab before editing a unit. Click the wrench icon next to the unit you want to edit in the 'Units' tab of the work area.

When shown on the map, a unit is represented by an icon with a caption displaying its name.



The icon is selected during the configuration process and can be chosen from a standard set of icons or uploaded from your device on the Icon tab.

The orientation of the icon can be adjusted to match the course or direction of the unit, as defined in the unit properties.

